

Instrument Security Procedures

Model:

Fluke 317/319

Product Name:

True RMS Clamp Meter

Instrument Description:

Fluke 317/319 true RMS clamp meter

Memory Description:

Fluke 317/319 has 1 memory devices: U11, micro controller, TI MSP430FE427, 32kB Flash, 256B RAM, contains operating code for the product and calibration constants.

Memory Cleaning Instructions:

The user-controlled storage operation (other than calibration constants) is the storage of Zero, Min Max and Average. This memory is cleared when the product is powered off.